


Board Dimensions



II. Jumper Settings & Connectors

Embedded Control Logic Settings

Jumper	Description
JP1	Open: System power ON/OFF via JP2 Short: System power ON/OFF via power supply switch
JP2	Short 1-2: System power ON/OFF either by front panel power button PWRBT1 or via ACPI compliant Microsoft Windows software Short 2-3: System power ON/OFF via front panel power button PWRBT1
PWRBT1	Power ON/OFF push button connector to front panel
CN6	6-pin cable to CPU card; used for Microsoft Windows Soft-power ON/OFF (ACPI compliant)
EXT-SMI1	External SMI connector to front panel

III. Pin Assignments

20-pin ATX Power Connector: CN1

Brown	3.3V	11	1	3.3V	Brown
Blue	-12V	12	2	3.3V	Brown
Black	GND	13	3	GND	Black
Green	PS-ON	14	4	5V	Red
Black	GND	15	5	GND	Black
Black	GND	16	6	5V	Red
Black	GND	17	7	GND	Black
White	-5V	18	8	PW-OK	Orange
Red	5V	19	9	5VSB	Purple
Red	5V	20	10	12V	Yellow

ATX6022/6VP4 User's Manual

4 PCI / 1 ISA / 1 PICMG Backplane

AT Power Connector: CN2

Pin	Signal	P8 & P9 Color
1	NC (P.G.)	orange
2	+5V _{DC}	red
3	+12V _{DC}	yellow
4	-12V _{DC}	blue
5-8	GND	black
9	-5V _{DC}	white
10	+5V _{DC}	red
11-12	+5V _{DC}	red

Output Power Connector: CN3

1	GND
2	GND
3	5VSB
4	3.3V
5	-5V
6	+5V
7	-12V
8	+12V

Keyboard Connectors: CN4, CN5

1	KBCLK
2	KBDATA
3	No Connector
4	GND
5	Vcc

ATX6022/6VP4 User's Manual
4 PCI / 1 ISA / 1 PICMG Backplane

©Copyright 2001 by AXIOMTEK Co., Ltd.
All rights reserved.
November 2004, Version A2
Printed in Taiwan

Trademarks Acknowledgments

AXIOMTEK is a trademark of AXIOMTEK Co., Ltd.

Other brand names and trademarks are the properties and registered brands of their respective owners.

Specifications are subject to change without notice.